



Europäisches Patentamt
European Patent Office
Office européen des brevets



(11) Publication number: **0 518 574 A2**

(12)

EUROPEAN PATENT APPLICATION

(21) Application number: **92305195.7**

(51) Int. Cl.⁵: **G06F 11/32**

(22) Date of filing: **05.06.92**

(30) Priority: **10.06.91 US 713484**

(43) Date of publication of application:
16.12.92 Bulletin 92/51

(84) Designated Contracting States:
DE FR GB IT

(71) Applicant: **International Business Machines Corporation**
Old Orchard Road
Armonk, N.Y. 10504 (US)

(72) Inventor: **Dewitt, Jimmie Earl**
1902 S. Main Street
Georgetown, Texas 78626 (US)
Inventor: **Emrick, Samuel Lee**
8003 Weldon Springs Court
Austin, Texas 78726 (US)
Inventor: **Holck, Timothy Manfred**
1401 Romeria
Austin, Texas 78757 (US)
Inventor: **Summers, James Hoyet**
2001 Flint Rock Drive
Round Rock, Texas 78681 (US)

(74) Representative: **Killgren, Neil Arthur**
IBM United Kingdom Limited Intellectual
Property Department Hursley Park
Winchester Hampshire SO21 2JN (GB)

(54) Indicating resource utilization in a data processing system.

(57) A graphical system resource monitor is provided to depict, in real-time, a data processing system's internal resource utilization. A window or viewport of a data processing system displays user specified internal system resources, such as memory, CPU, or peripheral device availability/utilization. This graphical representation of the 'state' of the data processing system's resources is maintained in real-time, while the data processing system's resources is maintained in real-time, while the impact on the system's performance in providing such information is kept to a minimum. This is accomplished through a combination of various techniques, including specialized device drivers for the respective devices coupled with a unique data reduction technique. The graphical results of these resource monitors are continually updated in real-time. This real-time support provides an immediate and accurate representation of the internal operations of the data processing system. Further, these resources can be monitored at the process level of a multiprocessing system. These representations can be used by a user to identify, isolate, and fine-tune the data processing system's resources to improve the overall efficiency of the system being monitored.

EP 0 518 574 A2

This invention relates to data processing systems and more particularly to a graphical monitor of a data processing system's resource utilisation.

In the quest for continued improvements in efficiency and utilisation of data processing systems, various types of data monitors have been developed to aid a user in understanding what is happening 'under the covers' of these systems. Data processing system resources of interest comprise such things as random access memory(RAM) usage, peripheral device usage, and central processing system (CPU) busy/idle time. These resources can give an operator of a data processing system key information on fine tuning the various system parameters to achieve a higher efficiency of the data processing system's overall throughput.

Users of operating systems need information on how much memory is being used. Information on memory utilisation, especially memory Working Set, is useful for showing if the physical memory in the computer is sufficient for the currently active applications. Insufficient memory allocation can cause inefficient system operations due to excessive swapping or paging that can occur based on this insufficiency. Prior products analysing system memory generally take on the order of 15-45 seconds to execute, depending on the actual amount of system memory exists in the system. The information presented is useful for determining the RAM consumed by an individual application, but only when intrusiveness of the tool, on the system being monitored, is not a factor. These prior products use a text screen. Other previously reported techniques and tools have relied on specialised hardware assistance for measuring or calculating RAM usage.

Other techniques have been used to measure other types of data processing system resources. Direct internal monitoring, by the system itself, is one technique known to exist. These techniques typically consume large percentages of the data processing system's own resources in capturing data, and write the captured data to some type of mass storage device. Then a subsequent procedure is used to read and analyse this data (i.e. analysis not in real time).

Device utilisation for peripheral devices has historically been measured directly by precisely measuring the start-time and complete-time for each I/O (input/output). This allows a calculation of the individual I/O times. By summing these I/O times over a given period it was possible to calculate total busy time. Then, device utilisation is calculated by dividing total busy time by total elapsed time. This approach creates two problems. First, it requires that the entity directly in control of the I/O (usually, either the device hardware and/or operating system) measure and record the I/O start/stop times. Next, it requires a hardware timer with sufficient resolution to accurately time these I/O events. On some systems, for example personal computers, neither of these criteria are met. In other words, the hardware or operating system does not measure I/O time. Further, the hardware timer is of such poor resolution (32 milliseconds) in many of today's personal computers that accurate I/O timings cannot be made. Thus, for existing personal computer systems, device utilisation is not obtainable using these conventional methods.

CPU idle time in a data processing system is the amount of time the computer's Central Processing Unit (CPU) is not being utilised by any task. Previous methods for measuring CPU idle time used a thread to perform a series of tasks. The number of tasks the thread performed was then compared with a hypothetical number of tasks that could have been performed, if the thread was allowed all available CPU time. This procedure is lacking in that the hypothetical number of tasks is different on different data processing systems. A system specific calibration algorithm is required to determine the minimum time the task(s) required to execute. This calibration method can be unreliable and presents many practical problems when moving between systems.

In general, the above types of systems are further lacking in that as performance data is gathered, it is written by the gathering system to a relatively slow mass storage device for further analysis. This is because the methods for capturing the data operate much faster than the methods used to analyse the data. Thus, the mass storage device is used as a buffer to allow the methods to operate at different operational speeds. Furthermore, the data generated by the data gathering system is of such a voluminous nature that the analysis method is unable to manage or maintain the large quantity of data. This constraint additionally required storage to an intermediate mass storage device.

As a result of this intermediate buffering, the analysis cannot be performed in real time, but rather is delayed. As such, any reports or other types of feedback of system performance and operation are chronically out of date with the actual performance. As today's data processing systems are supporting more complex operating environments, including support for multi-tasking and multi-users, this delay in performance data may cause critical system bottlenecks to continue unreported as the cause of any problem may have come and gone before being detected.

Other methods used to analyse the data require a significant amount of the gathering system's resources, such as the CPU. As a result, the analysis cannot be done in real time, as the analysis consumes such a large percentage of the resources, as it would bias the data to not be meaningful of the underlying system operation.

Some systems have attempted to overcome the above limitations, but in doing so have failed to maintain or capture information at a process level of a multiprocessing system. Rather, overall system usage can be

monitored, with no ability to focus on a particular process that may be causing the system to be performing poorly. This failure of process resolution results in showing that an overall system may be performing poorly, but no meaningful indication of which process in the system is the culprit.

It is therefore an object of the present invention to overcome the above drawbacks of the prior art.

According to the present invention, we provide a method for indicating resource utilisation of a data processing system, comprising the steps of: monitoring at least one process of said data processing system by said data processing system; generating resource usage data for said at least one process resulting from said monitoring; and displaying in real time said resource usage data of said data processing system.

Further, according to the present invention, we provide a system for indicating resource utilisation of a data processing system, comprising: monitoring at least one process of said data processing system by said data processing system; generator means for generating resource usage data for said at least one process resulting from said monitoring; and display means for displaying in real time said resource usage data of said data processing system.

The foregoing and other objects, aspects and advantages of the invention will be better understood from the following preferred embodiment with reference to the figures listed below, in which:

Figure 1 shows the conceptual model of the system performance monitor.

Figure 2 shows the functional model of the system performance monitor.

Figure 3 shows the categories of system memory being monitored.

Figure 4 depicts the working set calculation timing.

Figure 5 shows the system memory usage algorithmic flow.

Figure 6 shows a graphical representation of system resources being measured.

Figure 7a-7b shows the use of a viewport menus.

Figure 8 shows the flow for accepting user input and updating parameters.

Figure 9 shows how peripheral device utilisation is measured.

Figure 10 shows the construction of a high resolution system timer.

Figure 11a-11b shows the format of a generalised record which is stored in the internal device driver buffer.

Figure 12 the syntax structure for an application programming interface to a performance data gathering control program.

Figure 13 details the trace pipe records.

Figure 14 shows a data processing system.

Appendix A-1 thru A-13 is sample C source code for interfacing to the API.

The following method and system discloses a unique way to monitor a data processing system's resources, including RANK utilisation, CPU idle time, and peripheral device utilisation. This monitoring can be performed either internal to the system, or on a remote device attached via conventional communications methods. Various monitoring and tracing techniques are used for each respective resource being monitored. Data can be captured and presented at a process level in a multiprocessing environment. Other types of data processing system resources could be similarly monitored, such as data cache, using similar techniques of this invention, without departing from the claimed scope of this invention. The overall scheme is integrally packaged in an easy to use system, with real-time graphical depiction of resource parameters and support for user-modification of monitored variables. For purposes of the following discussion, it should be noted that 'real time' is defined by Webster's New Collegiate Dictionary to mean 'the actual time in which an event takes place with the reporting on or recording of the event practically simultaneous with its occurrence.'

Referring now to Fig. 1, the disclosed monitoring system 21 is conceptually divided into two distinct operations, a Data Collection Facility (DCF) 23 and a Resource Monitor (RM) 25. An application programming interface 27, or API, is used as the interface between these two operating models. A named pipe 29, as readily known to those of ordinary skill in the art and further described in "IBM OS/2 Programming Tools and Information, Version 1.2" is used to establish the connection between the DCF 23 and RM 25. The DCF 23 collects key performance data for various resources 31 being tracked. The RM 25 provides a depiction of resource usage. In the preferred embodiment this depiction is displayed graphically on a conventional data processing system display 33. As a named pipe 29 is used, the system as shown can have the Data Collection Facility 23 running on a computer distinct from the computer running the Resource Monitor 25, when the systems are connected via conventional communications techniques. This is because using the named pipe allows for network transparent operation.

Referring now to Figure 2, this system 21 is functionally divided into three sub-categories of operations, which are data collection techniques 35, data reduction techniques 37, and presentation techniques 39. The data collection techniques 35 include RAM working set utilization and sampling of peripheral devices. The data reduction techniques 37 include measuring an idle thread to determine CPU idle time, filtering of trace data and other reduction methods. Finally, the presentation techniques 39 include dynamic monitoring and multi-

viewport windowing. Figure 2 further illustrates this functional representation being overlayed over the conceptual model of Figure 1. As can be seen by Figure 2, the data collection techniques 35 are fully contained within the Data Collection Facility 23. The data presentation techniques 39 are fully contained within the Resource Monitor 25. The data reduction techniques 37 are coexistent in both the Data Collection Facility 23 and the Resource Monitor 25. As will be subsequently shown, the sharing in responsibility for the data reduction techniques 37 allows for efficiencies in both data capture and ultimate graphical depiction of the resource being monitored. The particular methodologies for each resource being monitored in the preferred embodiment will now be described.

RAM UTILISATION

One of the system resources 31 of Figure 1 which can be monitored is RAM utilisation. The disclosed monitoring method quickly (in milliseconds) calculates the memory utilisation for an entire operating system. It displays the results graphically in real time. In the preferred embodiment, the operating system is the IBM OS/2 operating system, but these concepts could be readily adapted by one of ordinary skill in the art to any other type of computer operating system.

Referring now to Figure 3, various categories of the total physical memory 41 are defined, with each respective category's utilisation being graphically depicted. Fixed Memory 43 is memory in a segmented swapping memory scheme that cannot be swapped out or discarded. It remains allocated in RAM as long as the application that owns this memory is loaded. Working Set Memory 45 is defined as (i) all the memory segments which are not swappable nor discardable, and (ii) all the memory segments which are swappable/discardable and which are used during the execution of the applicable scenario. Used Memory 47 is RAM allocated by the system and present in physical memory (i.e. memory that is allocated and not swapped out). Working Set Memory is not an instantaneous value. It is the memory used over a period of time called the "Working Set Period". The Working Set Period may be dynamically changed, as described in the Dynamic Monitoring section.

To calculate the Working Set Memory 45 of the whole system, an enhanced device driver provides a very quick calculation of memory utilisation. It uses a Working Set Period dynamically specified by the user. The device driver, which is coded in assembly language and runs at Ring 0 for best performance and uninhibited access to protected resources, obtains the Working Set for the whole system, not by session as was previously done in the prior art. Ring 0 will be known to those of ordinary skill in the art to be the ring running at the core level of an operating system, or most closest to the CPU hardware. Other levels, such as levels 1-3 in the preferred embodiment operating system of OS/2, run at respectively lower access levels of the CPU's internal resources.

In reference to Figure 4, the reported Working Set Memory is the percent of memory accessed over the last "Working Set Period" 51 seconds. It is updated, or snapshots are taken, every "Sampling Period" 53 seconds. This invention uses a sliding window 55 of memory use to calculate the Working Set Memory. The snapshot of memory taken every Sampling Period examines the Least Recently Used (LRU) timestamps for all memory segments (the methods for timestamping will be described later, in the device driver section). The LRU timestamps tell how recently a memory segment was accessed. For each snapshot, two values are found:

1. The latest LRU timestamp for the entire contents of memory. This value is the last time the most-recently-accessed part of memory was accessed. This value is used "Working Set Period" seconds later.
2. Which segments have been accessed since the LRU time stamp value that was saved "Working Set Period" seconds ago. The sum of the size of these segments comprises the Working Set 25 for that time period.

The procedure works as follows. The device driver walks through all the physical memory blocks. For each swappable, discardable block it does two comparisons:

1. Compares the block's LRU timestamp to the LRU timestamp acquired Working Set Period seconds earlier.

-- If the block's timestamp is greater than Working Set Period timestamp, then the block is in the Working Set, and the block size is added to the Working Set sum.

2. Compares the block's LRU timestamp to the maximum (newest) timestamp found thus far; if larger, it uses this new value for the current maximum timestamp.

The device driver returns the maximum (newest) LRU timestamp, the sum of the size (in bytes) of all the blocks in the Working Set, and the total physical memory.

This procedure is depicted in more detail in Figure 5. Various variables are initialized at 60. The next block of memory is read by the device driver at 72. The blocksize of memory being read is added to variable 70 which contains the count of Physical Memory at 74. A determination is made on whether the block is free, or unused, at 76. If not free, the blocksize is added to the variable 66 which contains the count of Used Memory at 78.

Next, a determination is made on whether the block is swappable/discardable at 80. If not, the blocksize is added to the variable 68 which contains the count of Fixed Memory at 82. Additionally, since Fixed Memory is defined to be part of Working Set, the blocksize is also added to the variable 64 which contains the count of Working Set memory at 86. If the block is swappable/discardable, processing continues to 84 where a check of the block's LRU timestamp is made. If the block LRU timestamp is greater than the maximum Working Set Period timestamp, the blocksize is added to the variable 64 which contains the count of Working Set memory at 86. In either event, the next determination is made at 88 on whether the block's LRU timestamp is greater than MaxTimestamp 62. If it is greater, the block LRU timestamp is saved as the new MaxTimestamp 62 at 90. Finally, a check is made to see if more blocks exist at 92. If so, processing continues at 72. If not, the device driver returns at 94 the values for MaxTimestamp, Working Set memory, Used memory, Fixed memory, and Physical memory as defined in Figure 3.

A graphics program, to be later described, invokes the device driver on a periodic basis, plotting the Working Set Memory as a percentage of the whole physical RAM in the user's machine. This invocation is achieved by the Data Collection Facility communicating via a system API call to the device. Information is then passed to the graphics program via the API over named pipes 29 of Figure 1. Referring again to Figure 3, the device driver is invoked every Sampling Period 53 to recalculate the Working Set Memory 45 (if the Working Set exceeds physical memory, it is displayed as 100%). A typical Sampling Period is 5 seconds and a typical Working Set Period is 60 seconds.

Referring now to Figure 6, Fixed and Used Memory are graphed as the upper 100 and lower 102 bounds, respectively, of the Working Set Memory. Since the Working Set Memory 104 is never less than the Fixed Memory nor more than the Used Memory, the graph shows the possible range of the Working Set Memory. This feature assists a user in providing a self-calibration mechanism such that the absolute possible minimum and maximum values are depicted on the graph automatically. The minimum absolute value is the computed value of Fixed memory, and the maximum absolute value is the computed value of Used memory.

For a stable scenario, if the Working Set Period is decreased, the reported Working Set will be lower because less memory is typically accessed over shorter periods of time. If the Working Set Period is increased, the Working Set is higher because more memory for more applications is typically accessed over longer periods of time.

The value of the Working Set Period parameter can affect the reported Working Set Memory. Longer periods cause the Working Set Memory to approach Used Memory, or the upper limit. Shorter periods cause Working Set Memory to approach Fixed Memory, or the lower limit. Fixed and Used memory are instantaneous values. Working Set, however, is defined as memory used over a period of time.

The following Table 1 describes how the RAM monitor can be used to interpret system resources.

5

Table 1 RAM Monitor Scenario Interpretation

10

Scenario	Interpretation
Note: The Working Set Period is set to 60 seconds for all scenarios.	
A large application is loaded. The working set shows a big increase. The fixed memory shows a small increase. The user decides not to use the application for a while, and a minute later the working set drops back down.	The loaded program is reported as part of the working set, and its fixed memory is reported as part of the system fixed memory (also included in the working set). For 60 seconds the memory used loading the program continues to be reported in the working set. Because the application is not active during the 60 seconds (and therefore most of the application's memory is not accessed), the working set drops back down after a minute even though the program is still loaded. The application's fixed memory, however, is still reported as part of the working set and as part of fixed memory.
A large application is	This application probably

15

20

25

30

35

40

45

50

55

5	loaded. The working set shows a bigger increase than expected.	uses more memory than it will during normal operation. The reported working set may drop later during normal operation.
10	A large application is loaded but then immediately ended. The reported working set rises and falls quickly.	When OS/2 unloads the application, OS/2 frees the application's memory. Freed memory is not reported in working set.
15	The swap-in and swap-out graphs show quite a bit of activity, even though the working set is not 100%.	When new segments must be swapped in or loaded, old segments that have not been accessed recently may need to be swapped out or discarded. The memory swapped out was reported in the working set if it was last accessed more than 60 seconds ago.
20		
25		Even with occasional swap activity, there may still be enough memory for good performance. More physical memory is not necessarily needed.
30	When the OS/2 system and the SPM application first start, fixed memory is higher than anticipated.	The fixed memory may include a large VDISK or DISKCACHE as as defined in the CONFIG.SYS file.
35	For a stable scenario, the working set period is changed from 60 seconds to 10 seconds. The reported working set is now lower.	The working set is lower because less memory is typically accessed in 10 seconds than in 60.
40		
45	For a stable scenario, the working set period is changed from 60 seconds to 1000 seconds. The reported working set is now higher.	The working set is higher because more memory for more applications is typically accessed in 1000 seconds than in 60 seconds.

50

55 This information on memory utilization, especially the Working Set Memory, is useful for showing if the physical memory in the computer is sufficient for the currently active applications. This technique further allows a user to ask 'what if?' questions without actually resetting the parameters that affect the variable or entity in question. In summary, this technique quickly calculates the Random Access Memory (RAM) utilization for an operating system as a whole, including the Working Set, Fixed, and Used amounts of RAM and displays these results graphically.

DYNAMIC MONITORING

The procedure for allowing a data processing system user to vary parameters that affect the display of dynamic monitors on a display screen will now be described. This procedure concerns the control of dynamic monitoring of a time-related function on a data processing system display when the function is affected by at least one variable. The data being monitored varies depending upon how certain parameters are set. As shown in Figure 7b, a dialogue box is presented to a user on the display screen, which the user has selected from the window's menu or action bar 110 as shown in Figure 7a. This dialogue box 120 contains fields 122 in which the user can enter new values of the parameters. After the user types in new, or modified, parameters, the program dynamically modifies the underlying function to use the new parameter's value. This is accomplished via an API call by the program controlling the dialogue box to the program controlling the data collection. As shown in Figure 8, a user parameter is queried at 112 via a dialogue box on the screen of Figure 7b. A check is made at 114 to determine if the parameter is valid. If not valid, an error message is displayed at 116 and the user parameter is again queried at 112. If valid, the new parameter is sent via a named pipe (29 of Fig. 1) to the Data Collection Facility API at 118. The Data Collection Facility accepts data and changes the parameter of the specified function at 119.

Although the preferred embodiment uses a dialogue box, other types of controls could similarly be used to obtain new parameters from a user, such as scroll bars, spin buttons, entry fields or command line parameters.

This method for varying parameters is used to modify the above-described RAM Working Set Period, the parameter which affects the dynamic display of the RAM Working Set Memory on the RAM Monitor window. As was previously discussed, the RAM Working Set Memory usually becomes lower when the user selects a lower RAM Working Set Period, and higher when selects a higher RAM Working Set Period.

PERIPHERAL DEVICE UTILIZATION

The general technique used for determining device utilization does not require high-resolution timing or changes to the hardware and/or operating system. Rather, this method periodically samples the device's status and records the number of times that the device returns a 'device busy' status. The technique used for generating the periodic rate can vary from implementation to implementation, and is not specific or critical to understanding the underlying device utilization measurement technique. For example, on a personal computer it is convenient to use the hardware timer interrupt, which occurs every 32 milliseconds on an IBM Personal Computer running OS/2, and every 55 milliseconds when running DOS. Further, the technique used to query device status will vary from device to device, but is similarly extendable to other types of devices without departing from the spirit and scope of the present invention. For example, an IBM Personal Computer ESDI disk drive provides continuous status at input port address x'3512' (hex). Other devices require that a device query command be sent to the device before the device returns status information.

Referring now to Figure 9, the collection program 140, which is a device driver in the preferred embodiment, receives interrupts 142 from a hardware timer 144. Each timer 'tic' causes the poll count to be incremented at 146. Then, the device 148 being measured is queried at 152, through its associated device controller 150 to determine if the device 148 is busy or not. This busy information is reported at 154 by the device controller 150. A check is made at 156 to see if the device reported a busy status. If so, the Busy Count is incremented at 158, and the collection ends until triggered again by a tic 142.

Once the collection program has a sufficient number of samples, as determined by the user specified or default parameters, the reporting program 162 then gathers the busy and total counts at 164, and calculates device utilization at 166 by dividing the busy count by the total count. This calculation is shown as follows:

$$\text{Device Utilization} = \text{Busy Count} / \text{Total Count}$$

This utilization number can then be reported by any number of methods, such as written to the display at 168 in either numeric or graphical form as hereinafter described, or written to a log file. This report program periodically invokes the collection program device driver, and plots the ratio of the number of busy tics to the total number of tics 142 as a ratio, in the preferred embodiment. The device driver is invoked every one second to recalculate the device utilization, although the frequency of this invocation is user-defined and modifiable by the procedures described elsewhere in this preferred embodiment description.

Because device utilization is being estimated by sampling, rather than measured directly, there is potential for error in the estimate. Statistical methods can predict this potential error. As will be readily understood by those of skill in the art, the sampling technique above uses repeated samples that have only two possible values, busy or not busy. Such samples are called Bernoulli samples, and follow the Binomial Distribution. Further, if the number of samples is relatively large, say greater than 20, then the Binomial Distribution may be approximated by the Normal Distribution. For the Normal Distribution, the error in the sample percentage as compared

to the actual percentage is less than:

$$\text{Error} = Z(a/2) * (x/n * (1 - x/n) / n) * * 1/2$$

where:

a = Desired confidence level (typically .95 or .99)

Z = Standard random variable for Normal Distribution

x = 'Successful' number of samples (in this case, busy samples)

n = Total number of samples

The value for Z(a/2) is found in statistical tables. For a 95 % confidence, Z(a/2) equals 1.960. For a 99% confidence, Z(a/2) equals 2.576.

As a specific example, consider that on an IBM Personal Computer running OS/2 a total of $10 * 1/0.032 = 312$ samples can be collected in 10 seconds. Further, consider that the largest value that the $(x/n * (1-x/n))$ can attain is .25 when the x is exactly one-half of n (This assertion can be proved by elementary calculus). One can then assert with 95% confidence that the maximum error found in a ten second device utilization estimate does not exceed:

$$1.96 * (.25 / 312) ** 1/2 = .055 = 5.5\%$$

A similar calculation would show that the maximum error in a one minute sample would be 2.3%. Thus, statistics show that the device busy sampling method described above does provide good accuracy in estimating device utilization. Further, this method is simpler and less expensive than previous used methods in obtaining device utilization information.

An alternative method of measuring peripheral device utilization is as follows. For measuring logical disk activity, file system events, which are generated when processes access the file system via an API, are traced and reduced by the methods described in the device driver section.

CPU ACTIVITY

CPU activity, or utilization, is measured in the preferred embodiment by starting a process and assigning the process to the lowest priority level in the system. Rather than tracking the amount of work that the process can perform, as was done in the prior art, this invention tracks the amount of time this lowest priority process is executing in the system. Since the process only executes when all other processes at a higher priority have completed their tasks, and no longer need the CPU, the amount of time the system is idle (or available to perform other tasks) is the amount of time the idle process was executing. In the preferred embodiment, data processing system tasks are divided into four classes: (i) Time Critical, which is the highest priority, (ii) Fixed High, which runs before any regular task, (iii) Regular, which is the normal class assigned to application programs, and (iv) Idle, which means don't run if Time Critical, Fixed High, or Regular priority tasks are ready to execute.

In the preferred embodiment, the OS/2 RAS Trace Facility, or SYSTRACE, provided by the OS/2 operating system is used to obtain an event trace of this low-level process system activity. This SYSTRACE facility is more fully discussed in the device driver section. Other similar types of system tracing facilities provided by other operating systems could be used in a similar manner to provide this utility, and not depart from the spirit and scope of the present invention. The following describes the specific SYSTRACE utilization.

DEVICE DRIVER

In the preferred embodiment, a device driver has been written to perform the following SYSTRACE utility. The device driver is installed in the normal way, being identified in the CONFIG.SYS file which the data processing system reads upon Initial Program Load (IPL). Special groups of instructions, called hooks, are included at key points in system and application programs in order to track execution flow. Each hook has a unique identity (Major code and Minor code) distinguishing it from all other hooks, and may or may not include key program variables, symbols, or return codes as data items. In the preferred embodiment of OS/2, there exists a facility known as SYSTRACE which provides means for hooks to be generated, collected, and stored in a buffer. Other operating systems provide similarly functionality through their own system utilities, and this utility can be considered as a generic tool for managing hooks.

The device driver intercepts all hooks passing through SYSTRACE, filters out undesired hooks or information contained therein, and passes only the precise hooks and information desired by the control program. The device driver and control program are the two elements comprising the previously discussed Data Collection Facility.

Upon device driver installation during system initialization, a 64K buffer is allocated in which data will be formatted and passed to the control program. This buffer is internally divided into two 32K buffers, with a portion of the second buffer being a communications area for use between the device driver and the control program.

EP 0 518 574 A2

The communication area is simply a portion of data processing system memory reserved for variables. This memory is accessible by both the device driver and the application program. The following Table 2 defines the variables which occupy the highest (i.e. last) 32 words of the second 32K buffer.

5			

	time_int	equ OFFEOH	First DD variable uses OFFEO & OFFE2
10	varAO	equ OFFEOH	One of words used on timetag arithmetic
	varA2	equ OFFE2H	One of words used on timetag arithmetic
15	start_time	equ OFFE4H	Second DD variable uses OFFE4 & OFFE6
	varBO	equ OFFE4H	One of words used on timetag arithmetic
	varB2	equ OFFE6H	One of words used on timetag arithmetic
20	elapsed_time	equ OFFE8H	Third DD variable uses OFFE8 & OFFEA
	var_FFE8	equ OFFE8H	One of words used on timetag arithmetic
	var_FFEA	equ OFFEAH	One of words used on timetag arithmetic
25	Dekko_SEL	equ OFFECH	Fourth DD: DEKKO FIRST OFFEC only 1 word
	PID	equ OFFEEH	Fourth DD: OTHER word for PID
	var_FFEC	equ OFFECH	One of words used on timetag arithmetic
30	var_FFEE	equ OFFEEH	One of words used on timetag arithmetic
	flush	equ OFFOH	if 1, flush hook, otherwise process normally
	var_FFFO	equ OFFOH	One of words used on timetag arithmetic
35	switch	equ OFFF2H	if not 0, switch buffers == "flush buffers"
	var_FFE2	equ OFFF2H	One of words used on timetag arithmetic
40	reals	equ OFFF4H	accumulates number of real mode hooks
	var_FFF4	equ OFFF4H	One of words used on timetag arithmetic
	var_FFF6	equ OFFF6H	One of words used on timetag arithmetic
45	var_FFF8	equ OFFF8H	One of words used on timetag arithmetic
	int_nesting	equ OFFAH	keeps up with nesting depth of interrupts
	var_FFFA	equ OFFAH	One of words used on timetag arithmetic
50	current_time	equ OFFCH	last DD variable uses OFFFC & OFFFE
	oldtime	equ OFFCH	save previous value
	bigtime	equ OFFEH	keep up with high word of time
55	shortbuf	equ 02020H	approx. 24 bytes effective

buffer size is 08000 - shortbuf

TABLE 2

Hooking

Also during this device driver install, the device driver saves a copy of the original SYSTRACE code located at the label "strp_common" for future use. A call to the OS/2 system routine DevHelp is used to obtain this address, as shown below:

SAMPLE ASSEMBLY CODE TO OBTAIN THE LOCATION
OF "strp_common"
AX:BX POINTS TO THE VARIABLE

```

mov     al,10D
mov     dl,DevHlp_GetDOSVar
call    DevHelp

```

TABLE 3

At some later time, the control program executes a "READ" to the device driver at which time the device driver installs a patch (modified code) over a portion of the SYSTRACE kernel code. The patch contains bi-modal (REAL or PROTECT, two differing addressing modes known to those of ordinary skill in the art to be a part of the Intel microprocessor architecture) code which can intercept hooks coming through SYSTRACE in either REAL or PROTECT mode, and filter out those tasks of interest, and perform other tasks, such as event tracing.

Unhooking

At a still later time, when the system is ready to shutdown, the control program executes a "WRITE" to the device driver, at which time the previously saved SYSTRACE kernel code is restored to its original position in the SYSTRACE facility, thus fully reinstating the original SYSTRACE function.

DATA GATHERING

Event tracing refers to a process of tracing events as they occur in the data processing system. Time stamps are associated with each event. The events are stored and processed in chronological order. Since the events are chronologically ordered, the events provide the sequence of activities that take place in the data processing system. An example of an event trace is shown in the following Table 4.

 EVENT TRACE EXAMPLE

5	Time_0	Event_0 data
	Time_1	Event_1 data
	Time_2	Event_2 data
	Time_3	Event_3 data
10	Time_4	Event_4 data
	Time_5	Event_5 data
	.	
	.	
	.	
15	Time_n-1	Event_n-1 data
	Time_n	Event_n data

TABLE 4

The SYSTRACE facility uses the low resolution system clock to place time stamps on events its processes. This is inadequate for the present invention when attempting to analyze performance on system resources. Thus, one of the data processing system's timers is used to determine the delta (difference) times between events and to replace the time in the SYSTRACE records shown above in Table 3 with a high resolution time tag.

TIMER

The hardware timer of the preferred embodiment is an Intel 8253 timer, which has multiple timers contained within. More detailed information on the 8253 timer can be found in the Intel Manual entitled "Intel Component Data Catalogue", available from the Intel Literature Dept. in Santa Clara, CA. Timer 0 is programmed to Mode 2. This mode provides a high resolution timer which starts at 0xFFFF and counts downward to 0x0000 and repeats. The timer function again begins at 0xFFFF, or in other words the timer rolls-over. Timer 3 is partially initialized so that the ordinary interrupt generated by other timers on the 8253 timer module are disabled. Ordinarily, when one of the timer/counters counts down to zero, an interrupt is issued so that the system will know that the time being counted has elapsed. In the preferred embodiment of this invention, an interrupt is not desired at the expiration of the timer/counter, and so this is inhibited by partially initializing Timer 3, also known as the watchdog timer (in other possible embodiments, the above timers may be real or they may merely be emulated by software techniques). The actual time interval being counted is approximately .8380953445 microseconds per tic. Referring now to Figure 10, an internal register 180, allocated in system main memory 182 and initialized to 0x0000, is incremented each time the interval timer rolls over from 0x0000 to 0xFFFF. The device driver reads at 170 the value from the internal timer 172 of the timer module 174. This value is then one's-complemented, so that the value effectively ranges from 0x0000 to 0xFFFF. This complemented timer value 176 is combined with the internal register value 178 to provide a 32 bit timer 180 which can count to approximately one hour before it rolls over. The high order word 178, which is 16 bits, is the internal register rollover counter, and the low order word 176, also 16 bits, is the complemented timer value. This 32 bit value is known as the Time Tag 180, whose use will be described below.

In order to maintain timing integrity, the above described internal timer must be read at least once every 55 milliseconds, in order to not miss a rollover. Activating SYSTRACE Major Code 04 will suffice for this requirement. Major Code 04 turns on or enables interrupts, which includes the timer interrupt. Since each timer interrupt occurs every 32 milliseconds in the preferred embodiment, this will guarantee that an event occurs (and an associated read of the 8253 timer) at least once every 55 milliseconds. This is because the 8253 timer is read every time an event, including an interrupt, occurs. Now that the timer operation is understood, discussion will now turn to when the timer is read.

Hooks are events that are capable of being monitored, and trigger a particular response in the data processing system. An event in OS/2 is usually described by two hooks, a pre-hook and a post-hook. For example, when an I/O request is made, the device driver generates a pre-hook signalling the system that a request is

about to be made to the I/O adapter. When the adapter completes the I/O request, the device driver signals the completion of the event with a post-hook. The time between the pre- and post-hooks represents the elapse time of the event. More specifically, as events occur, such as an I/O request, the kernel servicing the events calls the SYSTRACE routine with information describing the event. This allows SYSTRACE to process the event. Each time a hook arrives at the SYSTRACE patch code, meaning that a hook was invoked and that SYSTRACE is processing it, the timer is read and the high byte incremented if necessary (i.e. if the timer rolled over, as described above). The hook is examined to see if it is one of the desired hooks. If the received hook is one that is being monitored, it is processed further. Otherwise, it is flushed, or continues on with normal processing.

If the hook is an interrupt, 04/xx, the device driver measures the time spent processing interrupts. This is accomplished by matching the event called "start of an interrupt", called a pre-hook and which is generated when an interrupt handler begins to process the interrupt request, with the event "end of interrupt", called a post-hook and which is generated when an interrupt handler completes the processing of an interrupt request. As such, there is a one-to-one correspondence between pre- and post-hooks, and the timestamps of each are subtracted from one another to yield the time spent processing the interrupt.

It is also possible that after a pre-hook occurs, a subsequent pre-hook occurs before a corresponding post-hook occurs for the first pre-hook. This nesting of hooks is easily handled in that any post-hook received is paired with the most recently received pre-hook. In other words, after one hook starts, another can start, but the second will end before the first will end. In this nesting scenario, the end time minus the start time, and minus all nested activities, is how long the outer event took.

If the hook is a Mode Switch, 02/xx, the device driver measures the time spent in the REAL mode of the CPU by tracking the time from the first mode switch until the scheduler dispatches a different process. This time is then subtracted from the time when a mode switch to PROTECT mode occurs.

If the hook is a Thread Dispatch, 12/01, the device driver first saves the process identification (PID) and thread identification (TID) from its data area (PID and TID is common terminology in OS/2 architected systems; the PID is a 16-bit number that uniquely identifies a process within the OS/2 environment. The PID value starts at 0001 and increments each time a process is created. TID's are required as several threads can exist in one process). Then, the device driver examines its data to see if it has a PID identical to the PID in the previous Thread Dispatch hook 12/01, in which case the hook is flushed. Otherwise, the time spent in interrupts and the time spent in REAL mode is appended to the existing Thread Dispatch 12/01 data, which is the PID and TID provided by the scheduler describing the event. The entire Thread Dispatch hook is reformatted to conform to standard PERFMON/DEKOVERT format, as shown in Figure 11a and described later, and written to one of the device driver's 32K buffers. The two registers holding the accumulated Interrupt time and the REAL mode time are then reset to zero.

If the hook is a FileSystem hook, 30/xx, then the current TID 191 is inserted ahead of the Normal Data, as shown in Figure 11b.

The above listed, and other, hooks of interest are also reformatted so that they resemble the PERFMON/DEKOVERT format, and written to one of the 32K buffers. The first eight bytes of each record are the Major Code 183, the Minor Code 184, the Data Length 185, a Flag 186, and the four byte Time Tag 188, as shown in Figure 11. The subsequent bytes shown, DD1 - DDn at 189 are the hook data. When one of the buffers is full, i.e. has used 24K of its 32K space, the buffers are switched using conventional programming techniques, and the full 32K buffer is made available to the control program. Data collection continues in the other 32K buffer.

The device driver also provides for swapping these buffers on a signal from the control program, in order to be able to provide the control program with data accumulated up to that point. A similar operation occurs whenever a TRACE Command is issued, 00/02, hook is received and the first data byte is 0x00 (meaning that TRACE has been turned off). In this case, it is mandatory that the control program receive the current buffer immediately, as there will be no further accumulation of data in either buffer.

Communication between the control program and the device driver is achieved by using the communication area in the respective 32K buffer as follows. In order for the control program to reset the device driver and the device driver's buffers, the control program loads a control word in the communication area to the value '2', as shown in Table 2. When the device driver completes a reset, it changes this a value to '1'. If the control program desires to pause the device driver and buffer filling, the control program loads a control word in the communication area to a value of '1'. When the control program desires the device driver to resume, the control program loads this control word to a value of '0'. When the control program desires to shut down, or stop, the control program inhooks the device driver as previously described. Operation is then suspended until such time that the control program sends another READ command to the device driver.

DATA REDUCTION

Low-level event trace performance data is transformed into high level system activities. This is accomplished by the following methodology. First, pre-hook and post-hook events are matched, as previously discussed, and then these two hooks are transformed into one event. This is because a single record can be used to replace the pre- and post-hooks since it is now known how long the event took, and this event timing is the desired granularity of information needed. Additionally, as described above, events are filtered to only use information in the event records that are of interest to the control program.

APPLICATION PROGRAMMING INTERFACE (API)

The following describes the application programming interface (API) to the Data Collection Facility. This API allows client applications to retrieve performance data and access the Memory Analyzer.

The API is implemented through two named pipes called the System Pipe and the Trace Pipe. The System Pipe is used by a client application to send parameters to and receive responses from the Data Collection Facility. The Trace Pipe is used by a client application to receive continuous performance data. The Data Collection Facility creates both pipes; the client application issues the OS/2 function calls DosOpen and DosClose to access the pipes. Both pipes are created as message pipes in blocking mode (see the "IBM Operating System/2 Version 1.2 Programming Tools and Information" for additional information).

System Pipe

A client application controls the actions of the Data Collection Facility through the System Pipe. The client application reads from and writes to the pipe in message mode. Each message written to the pipe represents one parameter from the syntax diagram. A message must be an ASCII string (that is, a null-terminated string, or one byte of binary zeros) including numbers (for example, decimal 10 must be sent as the string "10").

The Data Collection Facility sends responses back to the client application through the System Pipe. The name, used by the client application on the OS/2 function call DosOpen, of the System Pipe in a local machine is `\\PIPE\\SYSTEM.SPM`; on a remote server the name of the pipe is `\\server_name\\PIPE\\SYSTEM.SPM`.

Output from the Memory Analyzer (`/THESEUS theseus_command`) is also sent from the Data Collection Facility to the client application through the System Pipe. First the return codes are sent. Then, output, if any, from the Memory Analyzer command is sent. Each message represents a single line from the Memory Analyzer; maximum line length is 100 characters. This output is followed by a **done message** represented by five pound signs (#####) followed by a null character (00). The System Pipe is disconnected by the Data Collection Facility when the client application closes the pipe with the OS/2 function call DosClose.

Fig. 12 details a syntax diagram for messages that may be sent to the Data Collection Facility through the System Pipe. Syntax parameters are explained in Table 5. A parameter is represented as a contiguous set of characters. Parameters with uppercase characters are keywords.

Each parameter must terminate with a null character (binary zero). For example, to send the comment "Performance data for **SERVER1**" to the **SPM** application, send the following messages:

/COMMENT

Performance data for SERVER1

Table 5 Data Collection Facility
Parameters

Parameter	Action
/START	Indicates the types of resources about which trace pipe records are to be sent by the Data Collection Facility. See also Table 8-3.
	* Indicates CPU, physical disk, RAM and swap resources when used with the /START parameter (does not indicate logical disk). Indicates all resources when used with the /STOP parameter.
	CPU Indicates CPU resources.
	PHYSICALDISK Indicates physical disk resources.
	LOGICALDISK Indicates logical disk resources.
	RAM Indicates random access memory resources.
	SWAP Indicates swapping resources
	Note: All trace pipe records without a specific type (designated as "No Type" in Table 8-3 are included whenever any of the preceding options are specified.
/STOP	Indicates the types of resources about which trace pipe records are <u>not</u> to be sent by the Data Collection Facility. See option descriptions under /START. See also Table 8-3.
####	Done message. Indicates the end of resource specification messages following the /START or /STOP parameter.

5	/COMMENT	Imbeds a comment with the collection data.
10	string	Comment to be imbedded in the current collection data. Comments cannot be longer than 40 characters; longer comments are truncated to 40 characters and are accepted without error by the Data Collection Facility. The string must be sent as a separate message if it contains embedded blanks.
20	/EXIT	Stops capturing data and releases the Data Collection Facility from memory. All processes started by the Data Collection Facility are also stopped (IDLECPU and THESEUS).
25	/INITDATA	Sends initialization records from the Data Collection Facility through the Trace Pipe. The following records are included:
30		<ul style="list-style-type: none"> - A Process Info record for the IDLECPU process. This is the process used by the Data Collection Facility to determine the time the CPU was idle. This process executes at idle priority, level 0 (zero).
35		<ul style="list-style-type: none"> - A System Info record.
40		<ul style="list-style-type: none"> - A Process Info record for all processes currently executing in the system. These records are only sent if the Memory Analyzer has been started (see the /THESEUS START parameter).
45		Note: The CPU resource must be started (see the /START CPU parameter in Table 8-3) in order to receive Process Info records.
50	/TOD	Specifies the interval (in seconds) between Time of Day records sent by the Data Collection Facility through the Trace Pipe.

55

interval The number of seconds between Time of Day records. The range of possible values is 1 to 100 seconds. The default is 5 seconds, but the **interval** parameter may have been set to another value by a previous application.

/RAM

Controls the periods used in sampling random access memory. See the **RAM** record description in Table 8-3 for information about the samples.

Note: This parameter does not imply **/START RAM**. See **/START RAM** at beginning of table for more information about enabling the **RAM** resource.

working_set_period

The time frame, in seconds, used in determining the amount of physical **RAM** included in the working set. Each sample represents the amount of **RAM** used during the last working set period. The range of possible values is 5 to 3600; the default is 60 seconds, but the **working_set_period** parameter may have been set to another value by a previous application.

Note: Until a full working set period has elapsed, the working set represents only the percentage of **RAM** in the working set since issuing the **/RAM** parameter or since the working set period was changed.

sample_interval

The number of seconds between **RAM** samples. A **RAM** trace pipe record is sent each time a sample is taken. The range of possible values is 5 to 3600; the default is 10 seconds, but the **sample_interval** parameter may have

been set to another value by a previous application.

5 **Note:** For performance reasons, the
 SPM application requires that
 the **working_set_period** parameter
 value divided by the
 sample_interval parameter value
 10 be less than or equal to 200.

15 **/THESEUS** Starts the Memory Analyzer if it has
 not already been started by the Data
 Collection Facility. Provides a
 programming interface to the Memory
 Analyzer from an application.

20 **Note:** The Memory Analyzer full-screen
 interface is not available from
 the copy of the Memory Analyzer
 started by the Data Collection
 Facility in this manner.

25 **START** Causes the Memory Analyzer to
 be started if it has not
 already been started by the
 Data Collection Facility.

30 **theseus_command**
 Any Valid Memory Analyzer
 command. The **theseus_command**
 must be sent as a separate
 message if it contains
 embedded blanks.

35 **Note:** All the Memory Analyzer commands
 (**theseus_command**) are
 interpreted directly by the
 Memory Analyzer, including the
 THESEUS LOG command. All
 40 actions will occur from the
 reference point of the Memory
 Analyzer started by the Data
 Collection Facility as though
 they were typed at the Memory
 45 Analyzer full-screen interface.

50 **/NOTHESEUS** Terminates the Memory Analyzer if it
 has been started by the Data Collection
 Facility. This saves the **RAM** overhead
 associated with the Memory Analyzer on
 the collection machine. However,
 Process Info records for processes

55

currently executing in the system
(excluding the IDLECPU process) are not
sent through the Trace Pipe. This
includes processes executing when the
/INITINFO parameter is sent.

/DEBUG	Indicates that the Data Collection Facility is to log parameters it receives from client applications to the log file SPMLOG.LOG in the working directory.
--------	---

One status message is sent to the client application by the Data Collection facility for every parameter that has a slash (/) as its first character. This status message provides an indication of the success of the request from the parameter. The format of a status message is described in the following table.

SPM Return Code	2 Bytes (Word)
Service Return Code	2 Bytes (Word)
Reserved	2 Bytes (Word)

Next, the output from any Memory Analyzer commands specified with the /THESEUS parameter (**theseus_command**) is sent to the client application. Each message represent a single line from the Memory Analyzer. A done message (####) follows this output.

Values that may be returned in the **SPM** return code field are contained in Table 6. All values are given in hexadecimal.

Table 6 SPM Return Codes

	Code	Description
5	X'0000'	No error, the parameters were accepted.
10	X'0007'	Invalid parameter. The service return code contains the sequence number of the parameter that failed. Each parameter beginning with a slash (/) will reset the sequence number to 1.
15	X'0010'	The <u>working_set_period</u> value is out of range (/RAM parameter).
	X'0011'	The <u>sample_interval</u> value is out of range (/RAM parameter).
20	X'0012'	The <u>sample_interval</u> value is not a multiple <u>working_set_period</u> value (/RAM parameter).
25	X'0013'	The <u>working_set_period</u> value divided by the <u>sample_interval</u> value is greater than 200 (/RAM parameter).
	X'0014'	The /TOD interval value is out of range.
30	X'0108'	Unable to issue the TRACE.EXE ON command to the OS/2 system through the OS/2 function call DosExecPgm.
	X'0208'	Unable to issue the TRACE.EXE OFF command to the OS/2 system through DosExecPgm.
35	X'0408'	Unable to start the IDLESPU.EXE program through the OS/2 function call DosKillProcess.
40	X'0409'	Unable to stop the IDLESPU.EXE program through the OS/2 function call DosKillProcess.
45	X'0806'	The Memory Analyzer does not recognize this OS/2 version.
	X'0807'	Unable to communicate with the Memory Analyzer.
50	X'0808'	Unable to start the THESEUS.EXE program through the OS/2 function call DosExecPgm.

55

X'0809' Unable to stop the **THESEUS.EXE** program through the OS/2 function call DosKillProcess.

X'1003' The device drive **THESEUS.SYS** was not loaded from the **CONFIG.SYS** file.

X'1005' An invalid version of the device driver **THESEUS.SYS** was not loaded from the **CONFIG.SYS** file.

X'2003' The device driver **SPMDCF.SYS** is missing in the **CONFIG.SYS** file.

X'2004' Errors occurred while initializing the **SPMDCF.SYS** device driver through DosOpen or DosRead.

Note: The service return code is the return code from the requested OS/2 service unless otherwise mentioned in this table.

TRACE PIPE

The Trace Pipe is used by a client application to retrieve performance data from the Data Collection Facility. The Trace Pipe is a one-way named pipe: Data Collection Facility to client application. On a stand-alone machine, the name of the pipe, as used by the client application on the DosOpen function call, is **\\PIPE\\TRACE.SPM**; on a remote server, the pipe name is **\\server_name\\PIPE\\TRACE.SPM**. The Trace Pipe is a message stream named pipe (as opposed to a byte stream named pipe) with a maximum message length of 8 kilobytes. The client application should send a **/STOP** or **/EXIT** message on the System Pipe to stop the collection and transmission of performance data through the Trace Pipe.

Data is queued in a buffer by the Data Collection Facility before transmission through the Trace Pipe. Messages on the Trace Pipe contain one or more complete trace pipe records. A message is transmitted through the pipe at least every 4 seconds, provided data is available.

The sequence of actions a client application would take to collect performance data from the Data Collection Facility is as follows:

1. Open the System Pipe.
2. Send appropriate messages to the Data Collection Facility (**SPMDCF**) through the System Pipe (including the **/START** message), obtaining return codes as applicable.
3. Open the Trace Pipe.
4. Read data from the Trace Pipe until ready to stop collecting.
5. Send a **/STOP** or **/EXIT** message to Data Collection Facility through the System Pipe, obtaining return codes as applicable.
6. Close the System and Trace Pipes.

TRACE PIPE RECORD FORMAT

The general format of records sent through the **SPM** Trace Pipe is:

Length of Record	Trace Pipe Code	Variable Length Data
(1 byte)	(1 byte)	(max. 250 bytes)

TRACE PIPE RECORDS

The records listed in Figs. 13A-C may be sent from the **SPM** application to a client application through the Trace Pipe.

TABLE DEFINITIONS**ASCII string**

A string of characters followed by a null character (ASCII 00). Maximum number of characters is 250.

data overflow

Indicates that data has been discarded by the Data Collection facility. Usually this occurs if the client application is not reading data from the Trace Pipe quickly enough.

doubleword

4 bytes in Intel format (that is, byte/word-reversed). In **IBM C/2**, this is an unsigned long integer (**ULONG**).

elapsed time

Total timertics encountered during the operation. This is not to be interpreted as time the operation was busy using the **CPU**, but rather, the time between when a request was submitted and when the operation completed. For example, a swap request is made by the swapper; then the swapper may give up the **CPU** to another process until disk I/O can complete; then the swapper completes the operation. The elapsed time includes the entire time, including the time the swapper was blocked waiting for the disk.

ID of the first physical disk

The **ID** assigned to the first physical disk by the system. Each physical disk is assigned a sequential number, beginning with the **ID** assigned to the first physical disk.

number of physical disks

The total number of physical disks installed in the system.

number of sectors

Number of 512-byte sectors.

physical disk ID

The **ID** assigned to the physical disk.

process name

This is the name of the process defined in the **.EXE** header or the file name of the **.EXE** file (does not include a period or the file extension).

time executing previous process

Total timertics encountered while executing the previous process (includes time spent at interrupt level [time in interrupts previous process]).

time in interrupts previous process

Total timertics encountered while at interrupt level while executing the previous process.

time since last Time of Day record

The elapsed timertics since the last record was sent. This value is provided for accurate calculations.

5 **timertic**

A value derived from the 8253/8254 chip. This value can be converted to microseconds by multiplying the value by 0.8380953445; that is:

microseconds = timertics x 0.8380953445.

10

TRACECMD

Indicates that the user issued a trace command.

15 **word**

2 bytes in Intel format (that is, byte-reversed). In **IBM C/2**, this is an unsigned short integer (**USHORT**).

GRAPHICAL PRESENTATION

20

In order to graphically depict the resource utilizations or performance monitors described above, the preferred embodiment of this invention uses OS/2 Presentation Manager window and graphics functions. This method allows a user to view multiple groups of related information in multiple windows (or viewports) simultaneously. One main window, called the parent window, contains all the other windows, called child windows, that display resource utilization information. As shown in Figure 6, the resource information is presented in the form of graphs which display percentage utilization of a certain data processing system resource. The resource utilization data is displayed to represent a user-configurable period of time (e.g. the last 600 seconds), or the viewing period 122 of Fig. 7b. Thus, it provides both instantaneous and recent/past records of resource utilization. A user can choose to view some or all of the resource monitors, as well as modify the display characteristics of the windows. Other information, or the same information in other forms, could be presented in the child windows. Presentation parameters, which control how, and when, the data is displayed in the child windows are changeable by the user from the main window's menu (action) bar. As will be appreciated to those of ordinary skill in the art, standard windows programming techniques are used to present the desired graphical representation to the OS/2 Presentation Manager interface. The Presentation Manager is the entity that actually presents the data in a display window or viewport. Other operating systems, such as DOS in combination with Microsoft's Windows, HP's New Wave, XWindows, or AIXWindows provide similar programming interfaces to a window-like presentations and could similarly be used in the presentation of resource monitors in their respective systems, without departing from the spirit and scope of the present invention.

35

Finally, Figure 14 depicts a generalized data processing system which is the preferred embodiment of this invention. A CPU 190, RAM 194, and peripheral device 196 (shown as a direct access storage device, or DASD), and interconnected via a bus structure. Similarly, ROS 192 and a keyboard 198 having a pointer/input device 200 are attached to this bus 204. These are the resources capable of being monitored in the preferred embodiment. Also attached to this bus is a display means 202, capable of rendering the resource monitor's results to a user. This display means is similarly attached to the common bus 204. Other variations having high speed paths between specific devices, and not a general bus as shown, would similarly fall within the realm of this invention, and would not be a departure from the scope of spirit of the herein claimed invention.

45

The present invention has been described for a specific embodiment, but it is equally well applicable to other data processing systems where a monitoring of the system resources is useful to the user of the system during the execution.

50

55

```

5  /* SPM API C Sample Program */
/*
/* © Copyright International Business Machines Corporation 1990-1991.
/* All rights reserved.
/*
10 /* WHAT THIS PROGRAM DOES:
/* -----
/*
15 /* This program opens the SPM System Pipe and uses the SPM
/* API to send commands to the SPM Data Collection Facility. Specifically,
/* the program instructs the Data Collection Facility to report swapping
/* activity. The program then opens and reads records from the Trace Pipe.
20 /* This program uses the swap records from the Trace Pipe and displays
/* those records on standard output. When the user hits F3, the program
/* instructs the SPM Data Collection Facility to stop sending data, and
/* then the program closes both pipes and exits.
/*
25 /* WHAT THIS PROGRAM DEMONSTRATES:
/* -----
/* This program provides an example of communication with the SPM Data
30 /* Collection Facility via its Application Programming Interface (API).
/* The program shows one way to use the SPM System Pipe and Trace Pipes.
/*
/*
35 /* *****
/* *****
/*
40 /* Include the required sections of the toolkit header files
/* *****
/* *****

#define INCL_DOSFILEMGR
#define INCL_DOSNMPPIPES
45 #define INCL_DOSERRORS
#define INCL_KBD

#pragma pack(1) /* IBM C/2 pragma to force structures onto byte boundaries */

```

Appendix A-1


```

5      /* ***** */
      /*          Include required header files          */
      /* ***** */

10     #include <os2.h>
      #include <stdio.h>
      #include <stdlib.h>
      #include <string.h>
15     #include "sample.h"
      #include "spm2api.h"

      /* ----- Global Definitions ----- */

20     SPMDCFREPLYDEF spmdcfRetCodes; /* SPM System Pipe return code */
                                      /* structure */

      /* ----- Prototype Definitions ----- */

25     BOOL    InitSPMDCF (PIPEDEF *, PIPEDEF *); /* Start communications with SPMDCF */
      BOOL    StopSPMDCF (PIPEDEF *, PIPEDEF *); /* Stop communications with SPMDCF */
      BOOL    ReadTraceData (PIPEDEF *); /* Read performance data */
30     USHORT  OpenPipe (PIPEDEF *); /* Open a named pipe */
      USHORT  ClosePipe (PIPEDEF *); /* Close a named pipe */
      USHORT  ReadPipe (PIPEDEF *, UCHAR *, USHORT); /* Read data from a named pipe */
      USHORT  WritePipe (PIPEDEF *, UCHAR *, USHORT); /* Write data to a named pipe */

35     /* ***** Start of Main Procedure ***** */
      /* ***** */
      /* MAIN: */
      /* main calls functions to 1) start communicating with the SPM Data */
40     /* Collection Facility, 2) read and interpret data from the SPM */
      /* Trace Pipe, and 3) close communications with the SPM Data */
      /* Collection Facility. */
      /* */
45     /* TracePipe and SystemPipe are defined and initialized in the header */
      /* file */
      /* ***** */

50     VOID cdecl main( )
    {

```

Appendix A-2

```

5      printf("SPM API C Sample Program\n");
      printf("© Copyright International Business Machines Corp. 1990,1991.\n");
      printf (" \nPress F3 to quit. \n\n");
      printf ("Initializing communication with SPM Data Collection Facility...\n");

10     /*-- Instruct SPM Data Collection Facility to send data --*/
      if (InitSPMDCF (&SystemPipe, &TracePipe) != NO_ERROR) {
          DosExit(EXIT_PROCESS, 1);
15     }

      printf("Reading swap data...\n");

20     /*-- Read data and output desired information --*/
      ReadTraceData(&TracePipe );

      printf("Closing communications with SPM Data Collection Facility...\n");

25     /*-- Instruct SPM Data Collection Facility to stop sending data --*/
      StopSPMDCF(&SystemPipe, &TracePipe);

30     printf("Done.\n");
    }

35     /*-----End of Main Procedure-----*/

/* ***** */
40 /* InitSPMDCF: */
/* Starts communication with the SPM Data Collection Facility. */
/* Opens System pipe, sends commands to send performance data about */
/* swapping activity, and then opens the Trace Pipe. */
45 /* Returns OS/2 service return code if an error occurs. */
/* ***** */
BOOL InitSPMDCF (PIPEDEF *SystemPipe, PIPEDEF *TracePipe)
{
50     SPMDCFREPLYDEF SPMDCFReply; /* SPMDCF return codes structure*/
    USHORT rc;

```

55

Appendix A-3

```

5  /*-- Start communication with the SPM Data Collection Facility by */
   /*-- opening the System Pipe. */
   if ((rc = OpenPipe (SystemPipe)) != NO_ERROR) {
       fprintf(stderr, "Error opening system pipe: rc = %d\n", rc);
       return rc;
10  }

   /*-- Instruct the SPM Data Collection Facility to send records */
   /*-- over the trace pipe when swapping is detected. */
15  if ((rc = WritePipe (SystemPipe, "/START SWAP", 0)) != NO_ERROR) {
       fprintf(stderr, "Error writing to system pipe: rc = %d\n", rc);
       return rc;
20  }

   /*-- Tell SPM Data Collection Facility that this message is complete. */
25  if ((rc = WritePipe (SystemPipe
                       ,PIPE_MSG_DONE
                       ,PIPE_MSG_DONE_LEN)
       ) != NO_ERROR) {
30  fprintf(stderr, "Error writing to system pipe: rc = %d\n", rc);
       return rc;
   }

35  /*-- Read and check the response from the SPM Data Collection Facility */
   if ((rc = ReadPipe (SystemPipe, (VOID *) &SPMDCFReply, sizeof(SPMDCFReply))
       ) != NO_ERROR) {
40  fprintf(stderr, "Error reading from system pipe: rc = %d\n", rc);
       return rc;
   }

45  if (SPMDCFReply.SPMRetCode != SPMNOERROR) {
       fprintf(stderr, "Error from SPMDCF: SPM return code = %d\n",
               SPMDCFReply.SPMRetCode);
       fprintf(stderr, "service return code = %d\n",
50  SPMDCFReply.ServiceRetCode);
       fprintf(stderr, "service category = %d\n",
               SPMDCFReply.SPMRetCode);
55  return SPMDCFReply.SPMRetCode;
   }

```

Appendix A-4

```

5      /*-- Open the trace pipe in order to read data from SPMDCF */
      if ((rc = OpenPipe (TracePipe)) != NO_ERROR) {
          fprintf(stderr, "Error opening trace pipe: rc = %d\n", rc);
          return rc;
10     }
    return NO_ERROR;
}

15
/* ***** */
/* ReadTraceData */
/* This function monitors the Trace Pipe for records indicating */
20 /* that swapping took place. If such a record is read from the Trace */
/* Pipe, it is printed. Function terminates when F3 is pressed. */
/* ***** */
BOOL ReadTraceData (PIPEDEF *TracePipe)
25 {
    static UCHAR      spmBuffer[MAX_SPMDCF_MSG_SIZE]; /* buffer for trace data */
    static UCHAR      *spmBufferPtr; /* place holder in trace buffer */
    static USHORT     bufferContentsSize, bytesScanned;
30    SPMTRACERECS *spmRecord; /* pointer to record in buffer */
    static USHORT     pipeHandle; /* local storage of named pipe file handle */
    static USHORT     rc;
35    static BOOL      done;
    KBDKEYINFO        KBDKey;
    HKBD              KBDHandle = 0;

40    pipeHandle = TracePipe -> Handle; /* local storage (better performance) */

    KBDKey.chScan = 0; /* Until the F3 key is pressed */
    done = FALSE;

45
    do {
        do {
50            /*-- Read data from the trace pipe; this call will block until */
            /*-- data is received. */
            /*-- If ERROR_MORE_DATA, then read a new buffer in. */

```

Appendix A-5

```

5      /*-- ERROR_MORE_DATA is not expected and only occurs in very */
      /*-- unusual circumstances. */

      rc = DosRead (pipeHandle
                    ,spmBuffer
10          ,MAX_SPMDCF_MSG_SIZE
                    ,&bufferContentsSize);

      if (rc == ERROR_MORE_DATA) {
15          fprintf(stderr, "Error reading trace pipe: ERROR_MORE_DATA\n");
      }
      } while (rc == ERROR_MORE_DATA);

20      /*-- check for errors */
      if ((rc != NO_ERROR) || (bufferContentsSize == 0)) {
          fprintf(stderr, "Error: broken trace pipe communication.\n");
25          return FALSE;
      } /* endif */

      /*-- set trace buffer pointer to point to current trace buffer */
30      spmBufferPtr = spmBuffer;

      /*-- set trace record pointer to point to current record in buffer */
      spmRecord = (SPMTRACERECS *) spmBufferPtr;
35

      /*-- scan the buffer for the trace records we want */
      for ( bytesScanned = 0;
40          bytesScanned < bufferContentsSize;
          /* advance spmRecord pointer */
          spmBufferPtr += spmRecord->RecLen,
          bytesScanned += spmRecord->RecLen)
45      {

          spmRecord = (SPMTRACERECS *) spmBufferPtr;

50          /*-- Check for spurious trace record lengths */
          /*-- This error should never happen under normal conditions. */

```

55

Appendix A-6

```

5      if (spmRecord->RecLen == 0) {
        fprintf(stderr, "Error: invalid trace record length = 0\n");
        return FALSE;
      }

10     /*-- Interpret what kind of record it is and compile stats */
    switch (spmRecord->Code) {
        /*-- In this sample program, we seek only Swap records --*/

15        /*-- Swap In record --*/
        case SWAPINCODE:

            printf ("Swap In: elapsed time: %lu timertics, ",
                    spmRecord->Data.Swap.ElapsedTime);
            printf ("%lu microseconds, ",
25                (ULONG) (0.8380953445 * spmRecord->Data.Swap.ElapsedTime));

            printf ("bytes: %lu\n", spmRecord->Data.Swap.Bytes);
            break;

30        /*-- Swap Out record --*/
        case SWAPOUTCODE:

            printf ("Swap Out: elapsed time: %lu timertics, ",
                    spmRecord->Data.Swap.ElapsedTime);
            printf ("%lu microseconds, ",
35                (ULONG) (0.8380953445 * spmRecord->Data.Swap.ElapsedTime));

            printf ("bytes: %lu\n", spmRecord->Data.Swap.Bytes);
            break;

40        default:
            /* ignore this record*/
            break;

50    } /* end switch */
} /* end for */

```

55

Appendix A-7

```

5      /*-- check if user wants to quit (F3 key) */
      KbdCharIn (&KBDKey, (USHORT) 1, KBDHandle); /* don't wait for keystroke */
      if (KBDKey.chScan == 0x3D) {
10         done = TRUE;          /* F3 key pressed */
      }

      } while ((rc == NO_ERROR) && (done == FALSE));

15     return TRUE;
    }

20     /* ***** */
    /* StopSPMDCF:                                     */
    /* Instructs the SPM Data Collection Facility to stop sending      */
25     /* performance data over the Trace Pipe. Then closes the Trace and */
    /* System Pipes.                                                 */
    /* ***** */
    BOOL StopSPMDCF (PIPEDEF *SystemPipe, PIPEDEF *TracePipe)
30     {
        SPMDCFREPLYDEF SPMDCFReply;
        USHORT rc;

35         /*-- Instruct the SPM Data Collection Facility to stop sending records */
        if ((rc = WritePipe (SystemPipe, "/STOP", 0)) != NO_ERROR) {
            fprintf(stderr, "Error writing to system pipe: rc = %d\n", rc);
40             return rc;
        }

        /*-- Tell SPM Data Collection Facility that this message is complete. */
45         if ((rc = WritePipe (SystemPipe
                               ,PIPE_MSG_DONE
                               ,PIPE_MSG_DONE_LEN)
                ) != NO_ERROR) {
50             fprintf(stderr, "Error writing to system pipe: rc = %d\n", rc);
            return rc;
        }
55

```

Appendix A-8

```

5      /*--- Read and check the response from the SPM Data Collection Facility */
      if ((rc = ReadPipe (SystemPipe, (VOID *) &SPMDCFReply, sizeof (SPMDCFReply))
          ) != NO_ERROR) {
10         fprintf(stderr, "Error reading from system pipe: rc = %d\n", rc);
         return rc;
      }
      if (SPMDCFReply.SPMRetCode != SPMNOERROR) {
15         fprintf (stderr, "Error from SPMDCF:  SPM return code      = %d\n",
                        SPMDCFReply.SPMRetCode);
         fprintf (stderr, "                service return code    = %d\n",
                        SPMDCFReply.ServiceRetCode);
20         fprintf (stderr, "                service category      = %d\n",
                        SPMDCFReply.SPMRetCode);
         return SPMDCFReply.SPMRetCode;
25     }

      /*--- Close the trace pipe */
      if ((rc = ClosePipe (TracePipe)) != NO_ERROR) {
30         fprintf(stderr, "Error closing trace pipe: rc = %d\n", rc);
         return rc;
      }

35     /*--- Close the system pipe */
      if ((rc = ClosePipe (SystemPipe)) != NO_ERROR) {
         fprintf(stderr, "Error closing system pipe: rc = %d\n", rc);
40         return rc;
      }

      return NO_ERROR;
45  }
  /* ***** */

```

50

55

Appendix A-9


```

/* ***** */
5  /* OpenPipe: */
/* Attempts to open the pipe indicated by the parameter Pipe. If the */
/* pipe is busy, this procedure waits until it becomes free, then */
/* tries to open the pipe again. If the pipe is again busy, then a */
10 /* return code of ERROR_PIPE_BUSY is returned. If any other error */
/* occurs, then the DosOpen return code is returned. */
/* ***** */
15 USHORT OpenPipe(PIPEDEF *Pipe)
{
    USHORT RetCode;
    USHORT ActionTaken;
20     USHORT OpenMode;
    BOOL    TriedOnce;

    /*--- Don't open the pipe if it's already open */
    if (Pipe->IsOpen==TRUE) {
25         return(NO_ERROR);
    } /* endif */

30     TriedOnce = FALSE;
    RetCode = NO_ERROR;

35     /*--- Set the correct file mode for the named pipe we are about to open */
    if (PIPE->OpenMode & DUPLEX_PIPE) {
        /*--- System Pipe */
        OpenMode = (BASE_OPEN_MODE | READ_WRITE);
40     } else if (Pipe->OpenMode and OUT_BOUND_PIPE) {
        /*---Trace pipe */
        OpenMode = (BASE_OPEN_MODE | READ_ONLY);
45     }

    do {
50         /*--- Attempt to open the pipe */
        RetCode = DosOpen(pipe->Name,
                        &(Pipe->Handle),
                        &ActionTaken,
55

```

Appendix A-10

```

5         OL,
        0x0000,      /* FileAttribute */
        0x0011,      /* OpenFlag = Create or Open */
        OpenMode,    /* OpenMode */
        OL);         /* Reserved */
10    /*---If we've tried twice and we get an error return code, then return
    /*---the error return code.
    if ((TriedOnce) && (RetCode != NO_ERROR)) {

15        return(RetCode);

    } else {

20        /*--- act on the return code */
        switch (RetCode) {

25            case NO_ERROR:
                Pipe->IsOpen = TRUE;      /* Set flag that pipe is open */

                /*---Make sure that the named pipe is in the state that we want */
                RetCode = DosSetNmPHandState(Pipe->Handle,
30                    READ_WRITE_BLOCK | READ_PIPE_AS_MSG
                    );

                return(RetCode);
                break;

35            case ERROR_PIPE_BUSY:

40                /*---Wait until the named pipe is free or until time's up */
                DosWaitNmPipe(Pipe->Name, Pipe->BusyWait);
                break;

45            default:

                /*---An error occurred, so return the return code from the DosOpen */

50                return(RetCode);
                break;

55

```

Appendix A-11

```

5      } /* endswitch */

      } /* endelse first time DosOpen was tried, or no error */

10     TriedOnce = TRUE;          /* set flag to show we tried and failed*/

    } while (RetCode != NO_ERROR); /* enddo */

15    return RetCode;
  }
  /* ***** */

20

25
  /* ***** */
  /* ClosePipe:
  /* Closes the pipe indicated by the parameter and returns the DosClose
30  /* return code. Sets the pipe state in the Pipe structure.
  /* ***** */
  USHORT ClosePipe(PIPEDEF *Pipe) {
    USHORT RetCode;

35    RetCode = DosClose(Pipe->Handle);

    if (RetCode == NO_ERROR) {
40      Pipe->IsOpen = FALSE;
    } /* endif */

    return(RetCode);

45  }
  /* ***** */

50

```

Appendix A-12

55

```

5  /* ***** */
   /* WritePipe: */
   /* Writes data to the pipe indicated by the parameter Pipe. The data */
   /* is stored in Buffer, and the length of the data in BufLen. If the */
10  /* data is an ASCIIZ string, then setting BufLen to zero will cause */
   /* WritePipe to calculate the length of the string. */
   /*
   /* The DosWrite return code is returned with the exception that if
15  /* less data was written than in the data buffer, ERROR_MORE_DATA is
   /* returned. If a DosWrite error occurs, the number of bytes written
   /* is reset to zero.
   /*
20  /* ***** */
   USHORT WritePipe(PIPEDEF *Pipe, UCHAR *Buffer, USHORT BufLen)
   {
25     USHORT RetCode;
     USHORT DataLen;

     /*— calculate the length of the buffer if not specified */
30     if (BufLen == 0) {
         DataLen = strlen(Buffer) + 1;          /* ASCIIZ string */
     } else {
         DataLen = BufLen;
35     } /* end else */

     /*—write the data to the pipe */
     RetCode = DosWrite(Pipe->Handle, Buffer, DataLen, &(Pipe->BytesWritten));
40

     /*—check that the write succeeded */
     if (RetCode != NO_ERROR) {
         Pipe->BytesWritten = 0;
45     } else if (Pipe->BytesWritten < DataLen) {
         RetCode = ERROR_MORE_DATA;          /*— not all the data was written */
     } /* endif */

50     return RetCode;
   }
   /* ***** */

```

55

Appendix A-13

```

5  /* ***** */
/* ReadPipe: */
/* Reads the pipe indicated by the parameter. The data is read from */
/* the pipe into the specified buffer, and the length of the data */
10 /* is returned in the Pipe structure. BufLen indicates the size of the */
/* data buffer. */
/* Returns the DosClose return code. Sets number of bytes read to */
/* zero if an error occurs. */
15 /* ***** */
USHORT ReadPipe(PIPEDEF *Pipe, UCHAR *Buffer, USHORT BufLen)
{
    USHORT RetCode;

20     RetCode = DosRead(Pipe->Handle, Buffer, BufLen, &(Pipe->BytesRead));

    if (RetCode != NO_ERROR) {
25         Pipe->BytesRead = 0;
    }

    return RetCode;
30 }
/* ***** */

35

/* ***** SAMPLE C Sample Program Header file (.H) ***** */
40 /*
/* The SAMPLE header file defines symbolic constants used
/* in the SAMPLE.C file.
/* SAMPLE local procedure declarations may appear in this file to
45 /* ensure they have been declared before being used.
/*
/* © Copyright International Business Machines Corporation 1990, 1991
/* All rights reserved
50 /*
/* ***** */

```

55

Appendix A-14

```

5      /* Open Modes for DosCreateNmPipe */
      #define PRIVATE_HANDLE 0x0080
      #define DELAYED_WRITE_NOT_ALLOWED 0x4000
      #define DELAYED_WRITE_ALLOWED 0x0000
10     #define DUPLEX_PIPE 0x0002
      #define OUT_BOUND_PIPE 0x0001

      /* Open Modes for DosOpen */
15     #define BASE_OPEN_MODE 0x20C0 /* OpenMode 0010 0000 1100 0000 */
      #define READ_WRITE 0x0002 /* 0010 */
      #define WRITE_ONLY 0x0001
      #define READ_ONLY 0x0000
20

      /* Pipe Mode for DosMakeNmPipe */
      #define READ_WRITE_BLOCK 0x0000 /* Wait for data on read/write requests */
      /*
25     #define READ_WRITE_NO_BLOCK 0x8000
      #define BYTE_STREAM 0x0000
      #define MESSAGE_STREAM 0x0400
      #define READ_PIPE_AS_BYTE 0x0000
30     #define READ_PIPE_AS_MSG 0x0100
      #define SINGLE_INSTANCE_PIPE 0x0001

      /* ***** */
35     /* Structures and type definitions */
      /* ***** */

      /* The PIPEDEF structure holds information related to a pipe */
      typedef struct _PIPEDEF {
40         USHORT BytesWritten, BytesRead, Handle, RetCode;
         USHORT IsOpen, OpenMode, PipeMode;
         USHORT InSize, OutSize;
         ULONG BusyWait;
45         UCHAR Name[ 80 ];
         UCHAR *Buffer;
      } PIPEDEF;
50

```

Appendix A-15

55

PIPEDEF SystemPipe = {

```

5      /* ***** */
      /* SPM System Pipe (Communication between SPMDCF and Application) */
      /* ***** */
10     0,0,0,0, FALSE, /* Run time status fields */
      (PRIVATE_HANDLE /* Open Mode */
      DELAYED_WRITE_NOT_ALLOWED
      DUPLEX_PIPE      ), /* Receive and send data */
15     (READ_WRITE_BLOCK /* Pipe Mode */
      MESSAGE_STREAM
      READ_PIPE_AS_MSG
      SINGLE_INSTANCE_PIPE ),
20     256, /* Output Buffer Size */
      128, /* Input Buffer Size */
      5000L, /* Wait ms if busy pipe */
      "\\Pipe\\System.SPM", /* Name of the pipe */
25     NULL); /* Pointer to Pipe Buffer */

```

PIPEDEF TracePipe = {

```

30      /* ***** */
      /* SPM Trace Pipe (trace records sent from SPMDCF to application) */
      /* ***** */
35     0,0,0,0, FALSE, /* Run time status fields */
      (PRIVATE_HANDLE /* Open Mode */
      DELAYED_WRITE_NOT_ALLOWED
      OUT_BOUND_PIPE  ), /* Read data only */
40     (READ_WRITE_BLOCK /* Pipe Mode */
      MESSAGE_STREAM
      READ_PIPE_AS_MSG
      SINGLE_INSTANCE_PIPE ),
45     65535, /* Output Buffer Size */
      0, /* Input Buffer Size */
      5000L, /* Wait ms if busy pipe */
      "\\Pipe\\Trace.SPM", /* Name of the pipe */
50     NULL); /* Pointer to Pipe Buffer */

```

Appendix A-16

Claims

1. A method for indicating resource utilization of a data processing system, comprising the steps of:
monitoring at least one process of said data processing system by said data processing system;
generating resource usage data for said at least one process resulting from said monitoring; and
displaying in real time said resource usage data of said data processing system.
2. The method of claim 1 wherein said at least one resource is random access memory.
3. The method of claim 1 wherein said at least one resource is peripheral device.
4. The method of claim 3 wherein said peripheral device is any of direct access storage device or communication adapter.
5. The method of claim 1 wherein said step of displaying in real time said resource usage data is displayed on a data processing system display.
6. The method of Claim 5 wherein said resource usage data is displayed in windows of said data processing system display.
7. The method of Claim 5 wherein said resource usage data is displayed on a local data processing system display.
8. The method of Claim 5 wherein said resource usage data is displayed on a remote data processing system display.
9. The method of Claim 1 wherein said step of monitoring is partially performed by a device driver.
10. The method of Claim 1 wherein said step of monitoring is substantially performed by a device driver in tandem with a control program.
11. A system for indicating resource utilization of a data processing system, comprising:
monitor means for monitoring at least one process of said data processing system by said data processing system;
generator means for generating resource usage data for said at least one process resulting from said monitoring; and
display means for displaying in real time said resource usage data of said data processing system.
12. The system of claim 11 wherein said at least one resource is random access memory.
13. The system of claim 11 wherein said at least one resource is peripheral device.




FIG. 1




FIG. 2




FIG. 3




FIG. 4

62 MAX TIMESTAMP = 0
 64 WORKING SET MEMORY = 0
 66 USED MEMORY = 0
 68 FIXED MEMORY = 0
 70 PHYSICAL MEMORY = 0




FIG. 5

MAX TIMESTAMP
 WORKING SET MEMORY
 USED MEMORY
 FIXED MEMORY
 PHYSICAL MEMORY

94




FIG. 8




FIG. 6




FIG. 7A

Menu item	Action
Time Periods	Displays the Time periods dialog box.

The Time Periods dialog box lets the user specify times that data will be collected and displayed.

FIG. 7B




FIG. 9




FIG. 10




FIG. 11a




FIG. 11b




FIG. 12

SPM/2 Trace Pipe Records			
Record Description (Resource)	Trace Pipe Code	Data	Size
Process Info (CPU)	01	Process ID	Word
		Process name	ASCIIZ string
Process Switch (CPU)	02	Process ID (of dispatched process)	Word
		Time executing previous process (timertics)	Doubleword
		Time in interrupts previous process (timertics)	Doubleword
Time of Day (no type)	10	Hour	Byte
		Minutes	Byte
		Seconds	Byte
		Reserved	1 Byte
		Time since last time of day record (timertics)	Doubleword
		Day	Byte
		Month	Byte
		Year	Word

FIG. 13A

SPM/2 Trace Pipe Records			
Record Description (Resource)	Trace Pipe Code	Data	Size
System Info (no type)	12	Number of physical disks	Word
		ID of first physical disk	Word
		Total RAM installed (bytes)	Doubleword
		Reserved	22 Bytes
RAM (RAM)	13	Total swappable/ discardable RAM (bytes)	Doubleword
		RAM in working set (bytes)	Doubleword
		RAM not in working set (bytes)	Doubleword
		Free RAM	Doubleword
		Working set period	Doubleword
TRACECMD (no type)	17	Reserved	Byte
Data Over-flow (no type)	18	Reserved	4 Bytes
Disk Read (physical disk)	21	Physical disk ID	Word
		Elapsed time (timertics)	Doubleword
		Number of sectors	Word
Disk Write (physical disk)	22	Physical disk ID	Word
		Elapsed time (timertics)	Doubleword
		Number of sectors	Word

FIG. 13B

SPM/2 Trace Pipe Records			
Record Description (Resource)	Trace Pipe Code	Data	Size
Disk Write Verify (physical disk)	23	Physical disk ID	Word
		Elapsed time (timertics)	Doubleword
		Number of sectors	Word
DOS Open (logical disk)	24	Process ID	Word
		File spec	ASCIIZ string
		File handle	Word
DOS Read (logical disk)	25	Process ID	Word
		File handle	Word
		Number of bytes	Word
DOS Write (logical disk)	27	Process ID	Word
		File handle	Word
		Number of bytes	Word
DOS Close (logical disk)	28	Process ID	Word
		File handle	Word
Swap In (swap)	31	Elapsed time (timertics)	Doubleword
		Length of segment (bytes)	Doubleword
Swap Out (swap)	32	Elapsed time (timertics)	Doubleword
		Length of segment (bytes)	Doubleword
Comment (no type)	40	Comment string (maximum size of 40 characters + null)	ASCIIZ string

FIG. 13C




FIG. 14



Europäisches Patentamt
European Patent Office
Office européen des brevets



Publication number : **0 518 574 A3**

(12)

EUROPEAN PATENT APPLICATION

(21) Application number : **92305195.7**

(51) Int. Cl.⁵ : **G06F 11/32**

(22) Date of filing : **05.06.92**

(30) Priority : **10.06.91 US 713484**

(43) Date of publication of application :
16.12.92 Bulletin 92/51

(84) Designated Contracting States :
DE FR GB IT

(88) Date of deferred publication of search report :
25.08.93 Bulletin 93/34

(71) Applicant : **International Business Machines Corporation**
Old Orchard Road
Armonk, N.Y. 10504 (US)

(72) Inventor : **Dewitt, Jimmie Earl**
1902 S. Main Street
Georgetown, Texas 78626 (US)
Inventor : **Emrick, Samuel Lee**
8003 Weldon Springs Court
Austin, Texas 78726 (US)
Inventor : **Holck, Timothy Manfred**
1401 Romeria
Austin, Texas 78757 (US)
Inventor : **Summers, James Hoyet**
2001 Flint Rock Drive
Round Rock, Texas 78681 (US)

(74) Representative : **Killgren, Neil Arthur**
IBM United Kingdom Limited Intellectual
Property Department Hursley Park
Winchester Hampshire SO21 2JN (GB)

(54) Indicating resource utilization in a data processing system.

(57) A graphical system resource monitor is provided to depict, in real-time, a data processing system's internal resource utilization. A window or viewport of a data processing system displays user specified internal system resources, such as memory, CPU, or peripheral device availability/utilization. This graphical representation of the 'state' of the data processing system's resources is maintained in real-time, while the impact on the system's performance in providing such information is kept to a minimum. This is accomplished through a combination of various techniques, including specialized device drivers for the respective devices coupled with a unique data reduction technique. The graphical results of these resource monitors are continually updated in real-time. This real-time support provides an immediate and accurate representation of the internal operations of the data processing system. Further, these resources can be monitored at the process level of a multiprocessing system. These representations can be used by a user to identify, isolate, and fine-tune the data processing system's resources to improve the overall efficiency of the system being monitored.

EP 0 518 574 A3



European Patent
Office

EUROPEAN SEARCH REPORT

Application Number

EP 92 30 5195

DOCUMENTS CONSIDERED TO BE RELEVANT			
Category	Citation of document with indication, where appropriate, of relevant passages	Relevant to claim	CLASSIFICATION OF THE APPLICATION (Int. Cl.5)
X	EP-A-0 422 945 (IBM CORP.) * column 9, line 17 - column 14, line 52; figures 4,8,9 *	1,5,7,11	G06F11/32
A	---	2-4,11, 12	
X	PROCEEDINGS OF THE INTERNATIONAL CONFERENCE ON COMPUTER LANGUAGES, March 12-15, 1990, IEEE, New York, US; C. KILPATRICK: 'Using languages for capture, analysis and display of performance information for parallel and distributed applications' * page 180, right column, line 31 - page 182, left column, line 27 * * page 183, right column, line 19 - page 184, left column, line 32 * * page 187, right column, line 45 - page 189, left column, line 6 *	1,5,7,11	
A	---	2-4,11, 12	
A	ACM TRANSACTIONS ON COMPUTER SYSTEMS. vol. 5, no. 2, May 1987, NEW YORK US pages 121 - 150 J. JOYCE ET AL. 'Monitoring distributed systems' * page 121, line 8 - page 126, line 6 * * page 130, line 4 - line 29 * * page 145, line 7 - page 147, line 7 *	1-6, 11-13	TECHNICAL FIELDS SEARCHED (Int. Cl.5) G06F
The present search report has been drawn up for all claims			
Place of search THE HAGUE		Date of completion of the search 02 JULY 1993	Examiner GORZEWSKI M.
<p>CATEGORY OF CITED DOCUMENTS</p> <p>X : particularly relevant if taken alone Y : particularly relevant if combined with another document of the same category A : technological background O : non-written disclosure P : intermediate document</p> <p>T : theory or principle underlying the invention E : earlier patent document, but published on, or after the filing date D : document cited in the application L : document cited for other reasons * : member of the same patent family, corresponding document</p>			

EPO FORM 1503 (01.92) (P0001)